

NAHRBTNIK ZA NOTESNIK/TABLICO 40 CM (16") WOZINSKY CITY BREAK WPC-P1 ROZA (WPC-P1)

27,99€

SKU: 394959
Kategorije: Prenosne naprave, Torbice za notesnike

OPIS IZDELKA

WOZINSKY CITY BREAK WPC-P1 BACKPACK WITH USB PORT - PINK

The Wozinsky City Break WPC-P1 is a functional backpack for everyday use and travel. The water-repellent material helps protect the contents from moisture during light rain. The built-in USB port makes it easier to charge mobile devices on the go, while separate compartments let you keep your belongings neatly organised. Retractable handles allow you to switch carrying styles and use the backpack as a handbag as well. Side straps let you adjust its shape to match the contents. Choose the City Break backpack and enjoy comfort during your daily activities.

Specifications:

- **Brand:** Wozinsky
- **Model:** Wozinsky City Break WPC-P1
- **Dimensions:** 28 × 16 × 44 cm

- **Weight:** 820 g
- **Material:** 100% polyester
- **Colour:** pink

Key features of the Wozinsky City Break backpack:

- **Moisture protection:** the material repels water droplets, reducing the risk of the contents getting wet during light rain.
- **Convenient charging access:** the USB port makes it easy to connect your device to a cable without opening the backpack.
- **Better organisation:** separate compartments help you stay organised and quickly find the accessories you need.
- **Two carrying options:** retractable handles let you use the product as a backpack or a hand-carried bag.
- **Adjustable to your load:** side straps let you adjust the shape of the backpack depending on how much you're carrying.

Water-repellent material helps protect against moisture

The material of the Wozinsky City Break backpack repels water droplets, helping to protect the items inside from moisture. This is a practical feature during everyday outings and unexpected light rain. The backpack is not fully waterproof, so during heavy or prolonged rainfall it is advisable to take additional steps to protect its contents.

The USB port makes charging your devices easier

The built-in USB port lets you charge your devices more conveniently on the go. It allows you to connect a cable on the outside of the backpack without having to open it every time. This is a handy feature during your commute, walks, and travels when you want to keep your phone within easy reach.

Separate pockets help you stay organised

Several zippered compartments make it easy to separate your everyday accessories and keep the contents of the backpack tidy. The front pockets provide quick access to smaller items you frequently need. This means you don't have to rummage through the main compartment every time, and packing the things you need becomes much simpler.

Retractable handles let you use the backpack as a bag

The Wozinsky City Break can be worn on your back or carried by hand as a bag. The retractable handles let you adapt the carrying style to your current needs, and when not in use they can be tucked away so they stay out of the way. This feature comes in handy while travelling, getting in and out of vehicles, or carrying luggage over short distances.

Side straps let you adjust the shape of the backpack

The straps positioned on both sides allow you to adjust the external form of the backpack depending on how full it is. When you're carrying fewer items, you can compress its outer volume for a more compact silhouette. This makes it easy to adapt the backpack to your everyday needs and the amount of things you're transporting.

AR-SET d.o.o. Dobravica 10 A 8310 Šentjernej Davčna št.: SI16935381 Tel: 059 048 227